

Frequency Plans Examples (Class A - G Airspace)			
Class A (None in Hawaii)			
Two-way communications required (Helicopters typically do not fly in Class A)			
Contact the area ARTCC (Air Route Traffic Control Center)			
Note: HCF Approach is center in Hawaii as well as HNL Approach / Departure			
Class B (HNL – Honolulu, Oahu)			
Takeoff	Frequency	Landing	Frequency
1. ATIS	127.9	1. En-route	122.85
2. Clearance	121.4	<u>2. ATIS</u>	127.9
3. Ground	121.9	3. Approach	119.1
4. Tower	118.1	4. Tower	118.1
<u>5. Departure</u>	119.1 (124.8 East)	5. Ground	119.1
6. En-route (ITAF) Free	122.85		
Class C (OGG – Kahului, Maui)			
Takeoff	Frequency	Landing	Frequency
1. ATIS	128.6	1. En-route	120.65
2. Clearance (If IFR)	120.6	<u>2. ATIS</u>	128.6
3. Tower	118.7	3. Approach	120.2 (119.5 South)
<u>4. Departure</u>	120.2 (119.5 South)	4. Tower	118.7
5. En-route (ITAF) Free	120.65		
Class D (KOA – Kona, Hawaii)			
Takeoff	Frequency	Landing	Frequency
1. ATIS	127.4	1. En-route	127.05
<u>2. Tower</u>	120.3	<u>2. ATIS</u>	120.3
3. En-route Free	127.05	3. Tower	120.3
Class E (MUE – Waimea, Hawaii)			
Takeoff	Frequency	Landing	Frequency
1. AWOS	120.0	1. En-route	127.05
<u>2. CTAF</u>	122.9	<u>2. AWOS</u>	122.9
3. En-route	127.05	3. CTAF	120.0
Class G (HDH – Dillingham, Oahu)			
Takeoff	Frequency	Landing	Frequency
1. CTAF	123.0	<u>1. En-route</u>	122.85
2. En-route	122.85	2. CTAF	123.0

Note: Helicopters typically do not use ground control when arriving and departing HNL.

Hawaii Airport Frequencies

Hawaii Airport	Frequencies
HAWAII	
Bradshaw Army Airfield PHSF (BSF)	126.300 - Tower 124.700 - ATIS 122.100 - FSS 126.000 - Approach/Departure
PHTO (ITO) Hilo International Airport	118.100 - Tower 121.900 - Ground Control 126.400 - ATIS 119.700 - Approach/Departure 118.900 - Approach/Departure 126.600 - Departure 122.100 - FSS 122.200 - FSS 122.600 - FSS
Kaupulehu Heliport 00HI (PVT-private)	N/A (no radio)
Keahole-Kona International Airport PHKO (KOA)	120.300 - Tower 121.900 - Ground Control 127.400 - ATIS 119.700 - Approach/Departure 118.900 - Approach/Departure 122.100 - FSS 122.200 - FSS 122.600 - FSS
Upolu Airport - PHUP (UPP)	122.900 - CTAF
Waimea-Kohala Airport PHMU (MUE)	122.900 - CTAF
KAUAI	
Barking Sands, Kauai PHBK (BAH) PMRF (Pacific Missile Range Facility)	126.200 122.800
Lihue Airport PHLI (LIH)	118.900 - Tower 121.900 - Ground Control 127.200 - ATIS 126.500 - Approach/Departure 122.100 - FSS 122.600 - FSS
Port Allen Airport PHPA (PAK)	122.900 - CTAF
Princeville Airport HI01- CTAF	122.900
LANAI	
Lanai Airport PHNY (LNY)	122.900 - CTAF 119.300 - HCF Approach/Departure
MAUI	
Hana Airport PHHN (HNM)	122.900 - CTAF
Kahului Airport PHOG (OGG)	118.700 - Tower 121.900 - Ground Control 120.600 - Clearance Delivery 128.600 - ATIS 120.200 - Approach/Departure 119.500 - Approach/Departure
Kapalua-West Maui Airport PHJH (JHM)	122.700 - Unicom/CTAF
MOLOKAI	
Kalaupapa Airport PHLU (LUP)	122.900 - CTAF
Molokai Airport PHMK (MKK)	125.700 - Tower 121.900 - Ground Control 128.200 - ATIS 124.100 - Approach/Departure 122.100 - FSS
Panda (PVT- private)	N/A
East Molokai (PVT- private)	N/A

OAHU	
Dillingham PHDH (HDH)	123.000 - Unicom/CTAF
Honolulu International Airport PHNL (HNL)	118.100 - Tower 123.900 - Tower 121.900 - Ground Control 121.400 - Clearance Delivery 127.900 - ATIS 279.400 - ATIS 118.300 - Approach/Departure 124.800 - Departure 122.100 - FSS 122.200 - FSS 122.600 - FSS 123.600 - FSS.
Kalaeloa (John Rogers Field) PHJR (JRF)	132.600 - Tower 119.800 - ATIS 123.800 - Ground
PHNG (NGF) Kaneohe MCAS (Marine Corps Air Station)	120.700 - Tower
Ford Island Landing Field (NALF) PHN (NPS)	122.800 - Unicom/CTAF
Wheeler Army Airfield PHHI (HHI)	119.600 - ATIS 126.300 - Tower 121.850 - Ground Control 118.300 - HCF Approach/Departure